

ANTI-SLIP PROPERTIES OF FLOOR COVERINGS

Customer	: EWAC Medical R. Born Galileistraat 20 1740 SE HEERHUGOWAARD
Manufacturer	: EWAC Medical Galileistraat 20 1740 SE HEERHUGOWAARD
TCKI order number	: 21.03.01239
Sample test number (Also invoice indication)	: Antislip tile 295x495
Sampling date	: 15-03-2021
Date of receipt	: 15-03-2021
Sample taken by	: The customer
Supplied by	: Customer, per mail
Type of material	: SMC1340 - warm pressed polyester
Colour	: Blue
Sort	: Fiber

1. Barefoot Ramp Test (EN 13451-1, Annex E)
2. Remarks

ORIGINEEL TCKI

Yours faithfully,
Velp, 24-03-2021



mrs. Ineke Geist, Head of laboratory.

- * The laboratory management can give you, on request, supplementary information concerning the test procedure and the measurement uncertainty of the results or can be found in the clarification document.
- * Results from this report only have reference to the tested material.
- * Duplication of this document is only allowed with preliminary permission of TCKI or client.

Q' 1. Determination of the anti-slip properties (EN 13451-1, Annex E)

Testing of floor coverings - Determination of the anti-slip properties - wet loaded barefoot areas; walking method - Ramp test in accordance with EN 13451-1, Annex E and CEN/TS 16165, Annex A.

TCKI order number : 21.03.01239
Sample test number: Antislip tile 295x495
Test date : 23-03-2021

Type of floor covering material:

See cover page

Size individual products (length x width) : 485 x 245 mm

Description of the surface characteristics of the floor covering:

Flat

Joint width : -

Contaminant: Water / 0.1 % soap solution

Type of test: barefoot

Test results:

Maximum angle of inclination in degrees:	
Test walker 1	Test walker 2
> 30.0	> 30.0
> 30.0	> 30.0
> 30.0	> 30.0
Average maximum angle of indication: >30	

2. Opmerkingen

Ordernummer TCKI: 21.03.01239
Steekproefnummer: Antislip tile 295x495

The product is classified as class C according to EN 13451-1 Annex E.